

REAR CARRIER

Accessory Name	Parts Number	Application Model	Issue Date	Publication No.
REAR CARRIER	08L70-MLA-J00	CMX1100A/D	2021.03	MII 17667
REAR CARRIER (AC)	08L71-MLA-A00	CMX1100A/D	2021.03	MII 17667

Introduction

ALL INFORMATION, ILLUSTRATIONS, DIRECTIONS AND SPECIFICATIONS INCLUDED IN THIS PUBLICATION ARE BASED ON THE LATEST PRODUCT INFORMATION AVAILABLE AT THE TIME OF APPROVAL FOR PRINTING. Honda Motor Co., Ltd. RESERVES THE RIGHT TO MAKE CHANGES AT ANY TIME WITHOUT NOTICE AND WITHOUT INCURRING ANY OBLIGATION WHATSOEVER. NO PART OF THIS PUBLICATION MAY BE REPRODUCED WITHOUT WRITTEN PERMISSION. THIS MANUAL IS WRITTEN FOR PERSONS WHO HAVE ACQUIRED BASIC KNOWLEDGE OF MAINTENANCE ON Honda MOTORCYCLES, MOTOR SCOOTERS OR ATVS.

Honda Dealer:

Please give a copy of these instructions to your customer.

Customer:

To install this accessory requires specialized knowledge, special tools and equipment. It is recommended to have a Honda dealer install this accessory.

How To Read These Symbols

Your safety, and the safety of others, is very important. To help you make informed decisions we have provided safety messages and other information throughout this manual.

NARNING You CAN be KILLED or SERIOUSLY HURT if you don't follow instructions.

♠ CAUTION You CAN be HURT if you don't follow instructions.

★NOTICE The purpose of this message is to help prevent damage to your vehicle, other property, or the environment.

NOTE Things you want to know, things that are useful to know.

Follow the instructions of the Service Manual.

Follow the other symbol instructions of the "Installation Instructions BASIC".

Instruction Other Symbols

The symbols used throughout this instructions show specific service procedures.

Refer to "Installation Instructions BASIC" for description of each symbol.

INFORMATION

ACAUTION

· To prevent burns, allow the engine, exhaust system, radiator, etc., to cool before installing the accessory.

NOTICE

• Take care not to damage the painted surfaces of the motorcycle.

NOTE:

· Save all removed parts unless otherwise indicated.

MAXIMUM LOADING CAPACITY

The weight of the cargo must not exceed the following maximum loading capacity:

Maximum Loading Capacity				
Rear carrier	3.0 kg (6.6 lb)			

PARTS LIST

When the instruction manual and installation instructions are included in this kit, be sure to give them to the customer.

Component	No.	Parts Name	Qty	Parts No.
	(1)	Rear carrier	1	-
(6)	(2)	Collar	4	-
	(3)	8×40 mm flange bolt	4	90036-GHB-740
	(4)	8×65 mm flange bolt	4	90036-GHB-790
	(5)	Label	1	-
	(6)	Grip end	2	-
	(7)	6×28 mm socket bolt	2	90113-MLA-A00
(5) (3) (4)				

TORQUE INFORMATION

Refer to the Service Manual for the torque values including standard torque of the removed parts. (iii)

INSTALLATION







