

CBR600 97/8 SSC

CONTENTS:

1 pair of fixing brackets marked L & R
2 x M x 16mm allen bolt
2 x M6 plastic washer
2 x ½” self tapping screw
2 x M6 flat steel washer
2 x rubber edge trim

Fitting instructions:

The cowl fits without the need to remove the grab rail.

First remove both seat panels, remove the seat (2 x M8 bolts) using a ring spanner or socket. Locate the bracket marked L to the left side of the seat, positioned as per the sketch below.

Be carefull to follow the sketch accurately, as the position of the bracket is important for the cowl to fit correctly.

With the bracket held in position drill a 3mm hole in the seat base using the hole in the bracket as a guide. The bracket can now be fixed using the self tapping screw and steel washer provided. The bracket hole is intentionally oversize to allow some adjustment.

Repeat for the bracket marked R on the right side of the seat.

The two brackets now provide the main fixing for the seat cowl, and may be left in place for easy fitting and removal.

The cowl can now be fitted to the seat with the edge trim around the front edges of the seat to prevent damage to the vinyl seat.

Refit the seat to the machine and replace the seat panels.

