

# Fitting Instructions

## MT-09 Belly Pan

### Kit Contents:

- 3 x Powder Coated Steel Brackets.
- 2 x Open Rubber Grommets
- 2 x Steel Collars
- 2 x Flanged Head Socket Screws M6 x 16mm
- 2 x flanged head socket screw M6 x 20mm

### Please refer to the pictures as a fitting guide

*Before assembly place card or similar protective material under the bike to protect the Belly Pan from accidental damage during Installation.*

First fit the open rubber grommets and the steel collar into the larger holes on the sides of the Belly Pan. *Fit the grommet first then slide in the collar.*

**Fig 1** shows the correct layout of the brackets. **It is for illustration purposes only. Please fit the brackets to the bike first and then attach the Belly Pan.**

**Fig 2, 3 and 4** show the brackets attached in their correct positions on the engine casing bolts.

The longer 20mm screws fit on the side brackets. The shorter 16mm bolts are for the large bracket mounting point on the underside of the Belly Pan.

Attach everything "finger tight" only to start with. This will allow best possible positioning of the Belly Pan to give even clearance all round before tightening. Check all fasteners **twice** to ensure they are all fully tight.



Fig 1



Fig 2



Fig 3



Fig 4