

MT-09 fly screen

Fitting Instructions

- Remove the two side bolts on the light unit.
- Place fly screen over the light unit and loosely re-fit the two bolts.
- Lift up fly screen to gain access to the Velcro tab and peel off the protective film.
- Press the screen firmly down into place.
- Fully tighten the two side bolts.
- **Check all fixings periodically.**